



Bridge Assembly




00811 Bridge Assembly 6-string, Complete
 00826 Bridge Cover Chrome

S17.pcx



00821 Bridge Assembly, 12-string, Complete
 00826 Bridge Cover Chrome

S38.pcx



00813 Channel Bridge 6 String Chrome
 00822 Channel Bridge 12 String Chrome
 00814 Bridge Saddles - 6 Saddle Bridge
 00824 Bridge Saddles - 12 Saddle Bridge
 00826 Bridge Cover Chrome
 00829 Base Bridge Chrome
 05201 Mounting Screw
 05302 Bridge Height Adjustment Screw
 05303 Bridge Intonation Screw - 6 Saddle Bridge
 05305 Bridge Intonation Screw - 12 Saddle Bridge
 06113 Bridge Intonation Spring
 06114 Bridge Height Adjustment Spring